MOXA EtherDevice™ Switch

EDS-408A/405A Hardware Installation Guide

First Edition, May 2006

Moxa Networking Co., Ltd.
Tel: +886-2-2910-1230
Fax: +886-2-2910-1231
www.moxa.com
support@moxanet.com (Worldwide)
support@moxa.com (The Americas)

P/N: 1802400100000

Overview

MOXA EtherDevice™ EDS-408A/405A series, which consists of 8 and 5 port smart Ethernet switches, provides an economical solution for your Ethernet connections. As an added bonus, the built-in smart alarm function helps system maintainers monitor the health of your Ethernet network.

Package Checklist

MOXA EDS-408A/405A is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.

- 1 MOXA EtherDevice Switch (EDS-408A or EDS-405A)
- Hardware Installation Guide
- CD-ROM with User's Manual and Windows Utility
- MOXA Product Warranty
- RJ45 to DB9 Console port cable
- Protective caps for unused ports
- Panel Mounting Kit (optional—must order separately)

Features

- **Advanced Industrial Networking Capability**
  - Redundant Self-Healing Ethernet Ring Capability (recovery time < 300 ms at full load)
  - Port-Based VLAN to ease network planning
  - QoS—IEEE802.1p and TOS/DiffServ to increase determinism
  - SNMP V1/V2c/V3 and RMON for high security network management
- **Designed for Industrial Applications**
  - Bandwidth management to prevent unpredictable network status
  - Port mirroring for online debugging
  - Automatic warning by exception through email, relay output
  - Automatic recovery of IP addresses from connected devices
  - Line-swap fast recovery (patent pending)
  - Redundant, dual DC power inputs
  - -40 to 75°C operating temperature range
  - IP30, rugged high-strength case
  - DIN-Rail or panel mounting ability
- **Useful Utilities and Remote Configuration Facility**
  - Configurable by Web browser, Telnet/Serial console, Windows utility, and SNMP
  - Send ping commands to identify network segment integrity

Panel Layout of EDS-408A/405A (Standard)

EDS-405A
Front Panel View



EDS-408A
Front Panel View



Top Panel View



Rear Panel View



1. Grounding screw
2. Terminal block for power input PWR1/PWR2 and relay output
3. Heat dissipation orifices
4. Console port
5. DIP switches
6. Power input PWR1 LED
7. Power input PWR2 LED
8. Fault LED
9. Master LED
10. Coupler LED
11. Turbo Ring logo
12. TP port's 100 Mbps LED
13. TP port's 10 Mbps LED
14. Model Name
15. 10/100BaseT(X) ports
16. Screw hole for wall mounting kit
17. DIN-Rail kit

Panel Layout of EDS-408A/405A (SC-type)

EDS-405A-MM-SC
Front Panel View



EDS-408A-MM-SC
Front Panel View



Top Panel View



Rear Panel View



NOTE: The appearance of EDS-405A-SS-SC is identical to that of EDS-405A-MM-SC.
The appearance of EDS-408A-SS-SC is identical to that of EDS-408A-MM-SC.

1. Grounding screw
2. Terminal block for power input PWR1/PWR2 and relay output
3. Heat dissipation orifices
4. Console port
5. DIP switches
6. Power input PWR1 LED
7. Power input PWR2 LED
8. Fault LED
9. Master LED
10. Coupler LED
11. Turbo Ring logo
12. TP port's 100 Mbps LED
13. TP port's 10 Mbps LED
14. Model Name
15. 10/100BaseT(X) ports
16. 100BaseFX ports
17. FX port's 100 Mbps LEDs
18. Screw hole for wall mounting kit
19. DIN-Rail kit

Panel Layout of EDS-408A/405A (ST-type)

EDS-405A-MM-ST
Front Panel View



EDS-408A-MM-ST
Front Panel View



Top Panel View



Rear Panel View



1. Grounding screw
2. Terminal block for power input PWR1/PWR2 and relay output
3. Heat dissipation orifices
4. Console port
5. DIP switches
6. Power input PWR1 LED
7. Power input PWR2 LED
8. Fault LED
9. Master LED
10. Coupler LED
11. Turbo Ring logo
12. TP port's 100 Mbps LED
13. TP port's 10 Mbps LED
14. Model Name
15. 10/100BaseT(X) ports
16. 100BaseFX ports
17. FX port's 100 Mbps LEDs
18. Screw hole for wall mounting kit
19. DIN-Rail kit

Mounting Dimensions (unit = mm)



DIN-Rail Mounting

The aluminum DIN-Rail attachment plate should already be fixed to the back panel of EDS-408A/405A when you take it out of the box. If you need to reattach the DIN-Rail attachment plate, make sure the stiff metal spring is situated towards the top, as shown by the following figure.

STEP 1:

Insert the top of the DIN-Rail into the slot just below the stiff metal spring.



STEP 2:

The DIN-Rail attachment unit will snap into place as shown.



To remove MOXA EtherDevice switch from the DIN-Rail, simply reverse Steps 1 and 2 as previously mentioned.

Wall Mounting (optional)

For some applications, you will find it convenient to mount EDS-408A/405A on the wall, as depicted by the following illustrations.

STEP 1: Remove the aluminum DIN-Rail attachment plate from EDS-408A/405A's rear panel, and then attach the wall mount plates, as shown by the diagram on the right.



STEP 2:

Mounting EDS-408A/405A on the wall requires 4 screws. Use the switch, with wall mount plates attached, as a guide to mark the correct locations of the 4 screws. The heads of the screws should be less than 6.0 mm in diameter, and the shafts should be less than 3.5 mm in diameter, as shown by the figure at the right.



NOTE Before tightening screws into the wall, make sure the screw head and shank size are suitable by inserting the screw into one of the keyhole-shaped apertures of the Wall Mounting Plates.

Do not screw the screws in completely—leave about 2 mm to allow room for sliding the wall mount panel between the wall and the screws.

STEP 3: Once the screws are fixed on the wall, insert the four screw heads through the large parts of the keyhole-shaped apertures, and then slide EDS-408A/405A downwards, as indicated. Tighten the four screws for added stability.



Wiring Requirements

WARNING

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your MOXA EtherDevice Switch.

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size.

If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

Pay attention to the following:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.

- NOTE: Do not run signal or communications wiring and power wiring through the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.
- Use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separate.
- It is strongly advised that you label wiring to all devices in the system, when necessary.

Grounding MOXA EtherDevice Switch

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices.

ATTENTION

This product is intended to be mounted to a well-grounded mounting surface, such as a metal panel.

Wiring the Relay Contact

The Relay Contact consists of the two middle contacts of the terminal block on EDS-408A/405A's top panel. Refer to the next section for detailed instructions on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor.

In this section, we explain the meaning of the two contacts used to connect the Alarm Contact.



FAULT: The two middle contacts of the 6-contact terminal block connector are used to detect both power faults and port faults. The two wires attached to the fault contacts form an open circuit when:

1. A relay warning event is triggered.
   OR
2. The EDS-408A/405A is the Master of this Turbo Ring, and the Turbo Ring is broken.
   OR
3. Start-up failure.

If neither of these three conditions is satisfied, the fault circuit will remain closed.

Wiring the Redundant Power Inputs

The top two contacts and the bottom two contacts of the 6-contact terminal block connector on EDS-408A/405A's top panel are used for EDS-408A/405A's two DC inputs. Top and front views of one of the terminal block connectors are depicted by the following illustrations:



STEP 1: Insert the negative/positive DC wires into the V-/V+ terminals, respectively.

STEP 2: To keep the DC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.

STEP 3: Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on EDS-408A/405A's top panel.

ATTENTION

Before connecting EDS-408A/405A to the DC power inputs, make sure the DC power source voltage is stable.

Communication Connections

EDS-408A models have 8 or 6 10/100BaseT(X) Ethernet ports, and 0 (zero) or 2 100BaseFX (SC/ST-type connector) fiber ports. EDS-405A models have 5 or 3 10/100BaseT(X) Ethernet ports, and 0 (zero) or 2 100 BaseFX (SC/ST-type connector) fiber ports.

10/100BaseT(X) Ethernet Port Connection

The 10/100BaseT(X) ports located on EDS's front panel are used to connect to Ethernet-enabled devices.

Next, we show pinouts for both MDI (NIC-type) ports and MDI-X (HUB/Switch-type) ports, and also show cable wiring diagrams for straight-through and cross-over Ethernet cables.

MDI Port Pinouts

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-

MDI-X Port Pinouts

Pin	Signal
1	Rx+
2	Rx-
3	Tx+
6	Tx-

8-pin RJ45



RJ45 (8-pin) to RJ45 (8-pin) Straight-Through Cable Wiring



RJ45 (8-pin) to RJ45 (8-pin) Cross-Over Cable Wiring


Switch Port (NIC Port)
Cross-Over Cable
Switch Port (NIC Port)
RJ45 Plug Pin 1
RJ45 Connector
Cable Wiring
RJ45 Connector
(Rx+) Tx+ 3 1 Rx+ (Tx+)
(Rx-) Tx- 6 2 Rx- (Tx-)
(Tx+) Rx+ 1 3 Tx+ (Rx+)
(Tx-) Rx- 2 6 Tx- (Rx-)

100BaseFX Ethernet Port Connection

The concept behind the SC/ST port and cable is quite straightforward. Suppose you are connecting devices I and II; contrary to electrical signals, optical signals do not require a circuit in order to transmit data. Consequently, one of the optical lines is used to transmit data from device I to device II, and the other optical line is used transmit data from device II to device I, for full-duplex transmission.

Remember to connect the Tx (transmit) port of device I to the Rx (receive) port of device II, and the Rx (receive) port of device I to the Tx (transmit) port of device II. If you make your own cable, we suggest labeling the two sides of the same line with the same letter (A-to-A and B-to-B, as shown below, or A1-to-A2 and B1-to-B2).

SC-Port Pinouts



SC-Port to SC-Port Cable Wiring



ST-Port Pinouts

ST-Port to ST-Port Cable Wiring

Cable Wiring



ATTENTION

This is a Class 1 Laser/LED product. To avoid causing serious damage to your eyes, do not stare directly into the Laser Beam.

Redundant Power Inputs

Both power inputs can be connected simultaneously to live DC power sources. If one power source fails, the other live source acts as a backup, and automatically caters to EDS-408A/405A's power needs completely.

Relay Contact

MOXA EtherDevice switch has one Relay Contact located on the top panel. For detailed instructions on how to connect the Relay Contact power wires to the two middle contacts of the 6-contact terminal block connector, see the ***Wiring the Relay Contact section*** on page 7. A typical scenario would be to connect the fault circuit to a warning light located in the control room. The light can be set up to switch on when a fault is detected.

The Relay Contact has two terminals that form a fault circuit for connecting to an alarm system. The two wires attached to the fault contacts form an open circuit when (1) a relay warning event is triggered, (2) EDS-408A/405A is the Master of this Turbo Ring, and the Turbo Ring is broken, or (3) start-up failure.

If none of these three conditions occur, the fault circuit will be closed.

Turbo Ring DIP Switch Settings

EDS-408A/405A series are plug-and-play managed redundant Ethernet switches. The proprietary Turbo Ring protocol was developed by MOXA to provide better network reliability and faster recovery time. MOXA Turbo Ring's recovery time is less than 300 ms—compared to a 3- to 5-minute recovery time for commercial switches—decreasing the possible loss caused by network failures in an industrial setting.

There are 4 Hardware DIP Switches for Turbo Ring on the top panel of EDS-408A/405A that can help setup the Turbo Ring easily within seconds. If you do not want to use a hardware DIP switch to setup the Turbo Ring, you can use a web browser, telnet, or console to disable this function.

EDS-408A/405A Series DIP Switches



The default setting for each DIP Switch is OFF. The following table explains the effect of setting the DIP Switch to the ON position.

DIP Switch	Setting	Description
------		Serves no function (reserved for future use).
MASTER	ON	Enables the EDS-408A/405A to be the Ring Master in a Turbo Ring topology, and enables the Turbo Ring break warning. If the EDS-408A/405A is the Master of this Turbo Ring, and the Turbo Ring is broken, the relay will form an open circuit.
	OFF	Disables the EDS-408A/405A from being the Ring Master in a Turbo Ring topology, and disables the Turbo Ring break warning.
COUPLER	ON	Enables the Turbo Ring Coupling function. Use port 5 and 6 of EDS-408A (port 2 and 3 of EDS-405A) to form the Ring Coupler path.
	OFF	Disables the Turbo Ring coupling function.
TURBO RING	ON	Enables plug-and-play Turbo Ring redundancy. Ports 7 and 8 of EDS-408A (ports 4 and 5 of EDS-405A) are used to form a Turbo Ring.
	OFF	Disables plug-and-play Turbo Ring redundancy function.

NOTE To switch on the Master or Coupler functions of the DIP switch, you have to enable the Turbo Ring Pole first.

NOTE If you do not enable any of the EDS-408A/405A switches to be the Ring Master, the Turbo Ring protocol will automatically choose the EDS-408A/405A with the smallest MAC address to be the Ring Master. If you accidentally enable more than one EDS-408A/405A to be the Ring Master, these EDS-408A/405A switches will auto-negotiate to determine which one will be the Ring Master.

LED Indicators

The front panel of the MOXA EtherDevice switch contains several LED indicators. The function of each LED is described in the following table.

LED	Color	State	Description
PWR1	AMBER	On	Power is being supplied to power input PWR1
		Off	Power is not being supplied to power input PWR1
PWR2	AMBER	On	Power is being supplied to power input PWR2
		Off	Power is not being supplied to power input PWR2
FAULT	RED	On	When (1) a relay warning event is triggered, (2) EDS-408A/405A is the Master of this Turbo Ring, and the Turbo Ring is broken, or (3) start-up failure
		Off	When a relay warning event is not triggered
MASTER	GREEN	On	When this EDS-408A/405A is the Master of this Turbo Ring
		Blinking	When this EDS-408A/405A is Ring Master of this Turbo Ring and the Turbo Ring has failed
COUPLER	GREEN	On	When the coupling function for this EDS-408A/405A is enabled
		Off	When the coupling function for this EDS-408A/405A is disabled
10M (TP)	GREEN	On	TP port's 10 Mbps link is active
		Blinking	Data is being transmitted at 10 Mbps
		Off	TP Port's 10 Mbps link is inactive
100M (TP)	GREEN	On	TP port's 100 Mbps link is active
		Blinking	Data is being transmitted at 100 Mbps
		Off	TP Port's 100 Mbps link is inactive
100M (FX)	GREEN	On	FX port's 100 Mbps is active
		Blinking	Data is being transmitted at 100 Mbps
		Off	FX port's 100 Mbps is inactive

Auto MDI/MDI-X Connection

The Auto MDI/MDI-X function allows users to connect the EDS-408A/405A's 10/100BaseTX ports to any kind of Ethernet device, without needing to pay attention to the type of Ethernet cable being used for the connection. This means that you can use either a *straight-through* cable or *cross-over* cable to connect EDS-408A/405A to Ethernet devices.

Fiber Ports

MOXA EDS-408A/405A's fiber switched ports operate at a fixed 100 Mbps speed and full-duplex mode to provide excellent performance. The fiber ports are factory-built as either multi-mode or single-mode SC/ST connectors. Therefore, you should use fiber cables that have SC/ST connectors at both ends. When plugging the connector into the port, make sure the slider guide is positioned to the right side such that it fits snuggly into the port.





The 100 Mbps fiber ports are switched ports, and perform as a domain, providing a high bandwidth backbone connection that supports long fiber cable distances (up to 5 km for multi-mode, and 40 km for single-mode) for flexibility of installation.

Specifications

Technology

Standards	IEEE802.3, 802.3u, 802.3x, 802.1D, 802.1w, 802.1p
Protocols	SNMP V1/V2c/V3, DHCP Server/Client, BootP, RMON, TFTP, SNTP, SMTP, RARP and EDS-SNMP OPC Server Pro (optional)
MIB	MIB-II, Ethernet-Like MIB, P-BRIDGE MIB, RMON MIB Group 1, 2, 3, 9, Bridge MIB, RSTP MIB
Forwarding and Filtering Rate	148810 pps
Processing Type	Store and Forward
Flow Control	IEEE802.3x flow control, back pressure flow control

Interface

RJ45 Ports	10/100BaseT(X) auto negotiation speed, F/H duplex mode, and auto MDI/MDI-X connection
Fiber Ports	100BaseFX ports (SC/ST connector)
Console	RS-232 (RJ45)
LED Indicators	PWR1, PWR2, FAULT, 10/100M (TP port), 100M (Fiber Port), MASTER and COUPLER
Relay Contact	One relay output with current carrying capacity of 1A @ 24 VDC
DIP Switches	Master, Coupler, Turbo Ring, Reserve

Optical Fiber

	Multi mode	Single mode
Distance, km	5	40
Wavelength, nm	1300	1310
Min. TX Output, dBm	-20	-5
Max. TX Output, dBm	-14	0
Sensitivity, dBm	-34 to -30	-36 to -32
Recommended Diam. (Core/Cladding) μm	50/125	9/125
	(1 dB/km, 800 MHz × km)	

Power

Input Voltage	12 to 45 VDC, redundant inputs
Input Current (@24V)	Max. 0.26A: (EDS-408A/405A) Max. 0.43A: (EDS-408A/405A-MM, EDS-408A/405A-SS)
Connection	One removable 6-pin terminal block
Overload Current Protection	Present
Reverse Polarity Protection	Present

Mechanical

Casing	IP30 protection, metal case
Dimensions	53.6 × 135 × 105 mm (W × H × D)
Weight	0.65 kg
Installation	DIN-Rail, Wall Mounting (optional kit)

Environmental

Operating Temperature	0°C to 60°C (32°F to 140°F) -40°C to 75°C (-40°F to 167°F) for -T models
Storage Temperature	-40°C to 85°C (-40°F to 185°F)
Ambient Relative Humidity	5% to 95% (non-condensing)

Regulatory Approvals

Safety	UL60950 (E212360), UL 508, CSA C22.2 No. 60950, EN60950 (pending)
EMI	FCC Part 15, CISPR (EN55022) class A
EMS	EN61000-4-2 (ESD), Level 3 EN61000-4-3 (RS), Level 3 EN61000-4-4 (EFT), Level 3 EN61000-4-5 (Surge), Level 3 EN61000-4-6 (CS), Level 3
Shock	IEC60068-2-27
Freefall	IEC60068-2-32
Vibration	IEC60068-2-6
WARRANTY	5 years

MOXA Internet Services

Customer satisfaction is our primary concern. To ensure that customers derive full benefit from our products, we have set up on-line support services to provide technical support, driver updates, product information, and user's manual updates.

E-mail for technical support:

support@moxanet.com	(Worldwide)
support@moxa.com	(The Americas)

Website for up to date product information:

www.moxa.com